









Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

CAUTION
KEEP ALL THE PARTS OUT REACH OF CHILDREN

HARDWARE	A  JCBC 40mm x18	B  x1	C  12mm x2	D  16mm x34	F  30mm x7	
	G  25mm x22	H  160mm x2	I  x6	J  x2	K  560mm x1	L  x65

PART	1  x1	2  x1	3  x2	4  x1	5  x1
	6  x1	8  x1	9  x1	10  x2	11  x1

