



nest .com

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

CAUTION

KEEP ALL THE PARTS OUT OF REACH OF CHILDREN .

ITEM	PHOTO	HAREWARE NAME	QTY
(A)		JCBCW M6 x 40mm	8
(B)		CSK M4 x 30mm	4
(C)		Allen Key M4	1
(D)		Wood Dowel M8 x 30	4

ITEM	PARTS NAME	QTY
(1)	Table Top	1
(2)	Apron	2
(3)	Table Side	2
(4)	Table Bottom	1

