

AIMON

WARRANTY & ASSEMBLY GUIDE




Read the instruction carefully. Remove all wrapping material staples and straps from the carton. Refer hardware and furniture part list for guidance. Be sure you have all parts before you start assembling. Place all wooden furniture part a clean and flat soft surface, such as carpet or rubbermat to prevent from scratched.

Caution

KEEP ALL PARTS OUT OF REACH OF CHILDREN.

ITEM	PHOTO	HARDWARE NAME	QTY
1		JCBB SCREW M6 X 70MM	8
2		FLAT WASHER M6	8
3		SPRING WASHER M6	8
4		ALLEN KEY M4	1

ITEM	PHOTO	PART NAME	QTY
A		TABLE TOP	1
B		LEG	4



1

