








Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

CAUTION
KEEP ALL THE PARTS OUT OF REACH OF CHILDREN.


	HARDWARE LIST		QTY
A		M4 x 45mm Chipboard Screw	6
B		M3.5 x 16mm Chipboard Screw	16
C		M3 x 12mm Chipboard Screw	9
D		Minifix Pin	6
E		Minifix Carn	6
F		Wood Dowel 6 x 25mm	20
G		Nail	40
H		Black Door Spring	6
I		Shelf Holder	27
J		Plastic Leg	4
K		Magnet	3
L		Magnet Plate	3

ITEM	PART LIST		QTY
1	Top Panel		1
2	Bottom Panel		1
3	Lelf & Right Panel		2
4	Lelf & Right Panel		2
5	Block Panel		1
6	Small Block Panel		1
7	Shelf Panel		3
8	Small Shelf Panel		3
9	Back Panel		1
10	Door Panel		3


CODING
-374005




Step 1




Step 2



Step 3



Step 4



Step 5

